

# ASSEMBLY INSTRUCTIONS

ITEM CODE : IN 4026

ITEM DESCRIPTION : 2 DRAWER BEDSIDE



1

Reverse the table top & place the leg as shown & align the leg to match the apron.



3

Fix the other leg set in the similar way



Place the bolt & washer in the cut out & tighten it with allen key provided as in Fig1.

2



4

Reverse the Bedside straight. Now your Bedside is ready for use.

