

# ASSEMBLY INSTRUCTIONS

ITEM CODE : IN 3628

ITEM DESCRIPTION : 1 DRAWER WRITING DESK




1

Reverse the desk top & place the leg as shown & align the leg to match the apron.




Insert the Bolt to fix the leg with the desk top and tighten the nut with the washer as shown in fig1

2



3

Fix the other pair of leg in the similar way



4

Reverse the desk straight. Now your writing desk is ready for use.



Fig. 1

