

ASSEMBLY INSTRUCTIONS

ITEM CODE : IN 4081

ITEM DESCRIPTION : Media Unit

1

Reverse the Media unit top & place the leg as shown & align the leg to match the apron.



2

Place the bolt & washer in the cut out & tighten it with allen key provided as in Fig1.



3

Fix the other leg set in the similar way



4

Reverse the Media unit straight. Now your Media unit is ready for use



Fig.1



